0F3MR620L110000 **FYA-M120**

901VT123 (1) M5x15 screws 901RD007 (2) M5 Self locking washer 0F3MR620L110004 (3)Bearing rest 003YAM027 (4) M20x1Nut 0F3MR620B110017 (5)M20 Notched Washer 0F3MR620L110007 (6)Spring stopper hub 003MG007 (7) Ball bearing 0F3CR620E07A008 (8)Spring pusher plate 0S1125 (9)Evoluzione primary springs 003SUZ118 (10)Primary spring support 0F3MR620L110003 (11)Pressure plate 0S2085 (12)Secondary spring 003YAM006 (13)Drum stopper hub 0F3SR540B140016 (14)idary spring support 0F3MR620L11A2A3 (15)Drum 0F3CR620E070038 (16)0 0 001MG025 (17)Steel balls 1/4' (18)0F3MR620B1101A3 Hub (19)0F3MR620B110045 (20)0A5MR620B110000

SLIPPER CLUTCH KIT FOR YAMAHA YZ 450 SM

ASSEMBLY INSTRUCTIONS

Pre-assemble the hub pack: place at the bottom of the grooves the 6 steel balls (17) onto the hub (18) using a small amount of grease. With an M6 screw fix the clutch drum (15) onto the clutch hub (18) in an at-rest position.

Insert the hub pack onto the main shaft.

Remove the screw used to hold hub (18) and drum (15) together.

Insert the drum stopper hub (13) into the hub housing (18) taking care that the three pins (16) inside the hub (18) place themselves in the three holes present on the drum stopper hub (13) and that they are on a level with the superior surface of the drum stopper hub.

Verify that the secondary spring support (14) is well inserted into its own housing inside the drum (15).

Insert the secondary spring (12) in its seat into the drum (15) with some grease.

Reinstall the clutch plates remembering to respect the position as in the original clutch. The total thickness of the disc pack should be 35,2

Verify that the primary spring support (10) is well inserted in its own housing inside the pressure plate (11).

Insert the Evoluzione Racing spring (9) into the pressure plate (11).

In order assemble the complete spring stopper kit starting from the spring pusher plate (8) with the shaped part facing up as shown in the picture. Insert the load bearing (7) and the spring stopper hub (6).

Finally, place the complete spring stopper pack inside the Evoluzione racing spring (9) beforehand mounted onto the pressure plate (11). At this point insert the pressure plate (11) on the drum (15). Insert the notched washer (5) in the relevant opening placed on the

upper part of the spring stopper hub (6), with the convex part facing up, then insert and screw the nut (4). Lock with the dynamometric key to the torque suggested by the manufacturer.

Assemble the complete bearing rest: mount the clutch push piece, and thrust washer of the original clutch into the bearing rest housing (3). Note that the clutch push rod may need adjusting on the other side of the engine, on the final drive sprocket cover, under the rubber

Position the bearing rest (3) into the relevant opening of the pressure plate (11) taking care to correctly align the openings and fix it with the six screws (1) and with the previously dismounted self locking washers (2).

NB: once the assembly is completed, repeatedly operate the clutch lever to check that pressure plate correctly performs the opening and closing movements.

GENERAL SAFETY REGULATIONS

PORTED THE DIRECTIONS TO PERFORM CORRECTLY THE SERVES THE RIGHT, WITHOUT NOTICE, TO INTRODUCE ANY TECHNICAL CHANGE VER DEEMED IT TO BE NECESSARY TO IMPROVE FUNCTION AND QUALITY OF

JUCTS.

SRL PRODUCTS ARE EXCLUSIVELY INTENDED FOR COMPETITION,
BILE ON MOTORBYKES ON PUBLIC ROADS.

OY OPERATIONS MUST BE PERFORMED BY A SKILLED TECHNICIAN AND MUST
ULOUSLY OBSERVED.

OLOUNING THE CULTICH MAKE A COMPLETE INSPECTION OF THE MOTORBIKE
RITS, IN ORDER TO VERIFY THE POSSIBLE PRESENCE OF FAULTS OR ANOMALIES
HIG! F

ONENTS, IN ORDER TO VERIFY THE POSSIBLE PRESENCE OF FAULTS OR ANOMALIES VEHICLE. SURE THAT THERE ARE NO MISSING/DAMAGED PARTS IN THE CLUTCH KIT. PARTS OF THE CLUTCH AND ITS COMPONENTS CAN HAVE SHARP SURFACE: <u>HANDLE</u>

THE COMPONENTS OF THE CLUTCH, BECAUSE OF THEIR SMALL DIMENSIONS CAN BE LLOWED: KEEP AWAY FROM CHILDREN.

RULES FOR PRODUCT CARE AND CLEANING

RULES FOR PRODUCT CARE AND CLEANING

ANODIZED and/or LEXAN PARTS: DO NOT USE on both glossy and matt anodized parts or on lexan components any type of acid or alkaline based degreaser. Use only neutral-based soaps. We recommend using a soft, non-abrasive, damp and clean microfiber cloth or synthetic sponge to avoid abrasions and scratches on surfaces, damp and clean microfiber cloth or synthetic sponge to avoid abrasions and scratches on surfaces, damp and clean microfiber cloth or synthetic sponge to avoid abrasions and scratches on surfaces, and provided to the special products. But also pickling agents or acids is prohibited.
Always wash your motorcycle cold, never hot.

Do not use pressure washers, steam cleaning machines or any type of high pressure washing system or with high operating temperatures, any type of washing of these types can damage or permanently unin the anodized surfaces or lexan.

STM ITALY Via A. Olivetti 15 - 10020 - Riva presso Chieri (TO) www.stmitaly.com - contact@stmitaly.com

